

SMOKE DETECTION PANEL XL No.5 SCHEDULE 'A' (SINGLE ADDRESS INPUTS)				
INPUT		OUTPUT		
ADDRESS	INITIATING DEVICES	ANNUNCIATOR MESSAGES	ACTIVATED RELAYS	ACTIVATED HVAC EQUIPMENT
051101	DUCT SMOKE DETECTOR	E-41-15 EXH. FAN SHUTDOWN TWR 1	POX-28-103	E-41-15 SHUTDOWN
051102	DUCT SMOKE DETECTOR	E-41-18 EXH. FAN SHUTDOWN	POX-29-112	E-41-18
051103	AREA SMOKE DETECTOR	ACS-41-15 AREA ALARM	POX-22-044	ACS-41-15
051104	DUCT SMOKE DETECTOR	ACS-41-15 DUCT ALARM		
051105	AREA SMOKE DETECTOR	ACS-41-4 AREA ALARM		
051106	DUCT SMOKE DETECTOR	ACS-41-4 DUCT ALARM	POX-20-021	ACS-41-4
051107	DUCT SMOKE DETECTOR	ACS-41-8 AREA ALARM		
051108	AREA SMOKE DETECTOR	ACS-41-8 DUCT ALARM	POX-21-031	ACS-41-8
051109	DUCT SMOKE DETECTOR	ACS-41-12 AREA ALARM		
051110	AREA SMOKE DETECTOR	ACS-41-12 DUCT ALARM	POX-22-041	ACS-41-12
051111	DUCT SMOKE DETECTOR	ACS-41-12 DUCT ALARM		
051112	DUCT SMOKE DETECTOR	ACR-41-12 SHUTDOWN		
051113	DUCT SMOKE DETECTOR		GROUP A	GROUP A
051114	DUCT SMOKE DETECTOR	ACR-41-11 SHUTDOWN		
051115	DUCT SMOKE DETECTOR			
051116	DUCT SMOKE DETECTOR	ACR-41-10 SHUTDOWN		
051117	DUCT SMOKE DETECTOR			
051118	DUCT SMOKE DETECTOR	E-41-21 EXH FAN SHUTDOWN	POX-30-121	E-41-21
051119	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 40 SW		
051120	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 43 SW		
051121	AREA SMOKE DETECTOR			
051122	AREA SMOKE DETECTOR	SMOKE IN SUB 41S	SPX-13-014	ALARM STATIONS
051123	AREA SMOKE DETECTOR			
051124	MANUAL PULL STATION	PULL STATION IN SUB 41S		
051125	MANUAL PULL STATION			
051126	MANUAL PULL STATION			
051201	AREA SMOKE DETECTOR	ACS-41-3 AREA ALARM TWR 1		
051202	DUCT SMOKE DETECTOR	ACS-41-3 DUCT ALARM	POX-19-014	ACS-41-3 SHUTDOWN
051203	DUCT SMOKE DETECTOR			
051204	AREA SMOKE DETECTOR	ACS-41-11 AREA ALARM	POX-21-034	ACS-41-11
051205	DUCT SMOKE DETECTOR	ACS-41-11 DUCT ALARM		
051206	AREA SMOKE DETECTOR	ACS-41-7 AREA ALARM	POX-20-024	ACS-41-7
051207	DUCT SMOKE DETECTOR	ACS-41-7 DUCT ALARM		
051208	AREA SMOKE DETECTOR	ACS-41-14 AREA ALARM	POX-22-043	ACS-41-14
051209	DUCT SMOKE DETECTOR	ACS-41-14 DUCT ALARM		
051210	AREA SMOKE DETECTOR	ACS-41-16 AREA ALARM		
051211	DUCT SMOKE DETECTOR	ACS-41-16 DUCT ALARM	POX-23-051	ACS-41-16
051212	DUCT SMOKE DETECTOR			
051213	DUCT SMOKE DETECTOR	ACR-41-9 SHUTDOWN	GROUP A	GROUP A
051214	DUCT SMOKE DETECTOR			
051215	DUCT SMOKE DETECTOR	ACR-41-8 SHUTDOWN		
051216	DUCT SMOKE DETECTOR			
051217	DUCT SMOKE DETECTOR	ACR-41-7 SHUTDOWN		
051218	DUCT SMOKE DETECTOR			
051219	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 40 SE		
051220	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 43 SE		
			GROUP A POX-25-073 POX-25-074 POX-26-081 POX-26-082 POX-26-083 POX-26-084 POX-19-014 POX-20-021 POX-20-024 POX-21-031 POX-21-034 POX-22-041 POX-22-043 POX-22-044 POX-23-051	ACR-41-7 SHUTDOWN ACR-41-8 ACR-41-9 ACR-41-10 ACR-41-11 ACR-41-12 ACS-41-3 ACS-41-4 ACS-41-7 ACS-41-8 ACS-41-11 ACS-41-12 ACS-41-14 ACS-41-15 ACS-41-16

SMOKE DETECTION PANEL XL No.5 SCHEDULE 'A' (SINGLE ADDRESS INPUTS)		
INPUT		ANNUNCIATOR MESSAGES
ADDRESS	INITIATING DEVICES	
051301	AREA SMOKE DETECTOR	ACS-41-13 AREA ALARM
051302	DUCT SMOKE DETECTOR	ACS-41-13 DUCT ALARM
051303	AREA SMOKE DETECTOR	ACS-41-5 AREA ALARM
051304	DUCT SMOKE DETECTOR	ACS-41-5 DUCT ALARM
051305	AREA SMOKE DETECTOR	ACS-41-9 AREA ALARM
051306	DUCT SMOKE DETECTOR	ACS-41-9 DUCT ALARM
051307	AREA SMOKE DETECTOR	ACS-41-1 AREA ALARM
051308	DUCT SMOKE DETECTOR	ACS-41-1 DUCT ALARM
051309	DUCT SMOKE DETECTOR	
051310	DUCT SMOKE DETECTOR	ACR-41-1 SHUTDOWN
051311	DUCT SMOKE DETECTOR	
051312	DUCT SMOKE DETECTOR	ACR-41-2 SHUTDOWN
051313	DUCT SMOKE DETECTOR	
051314	DUCT SMOKE DETECTOR	ACR-41-3 SHUTDOWN
051315	DUCT SMOKE DETECTOR	
051316	DUCT SMOKE DETECTOR	E-41-20 DUCT ALARM
051317	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 4
051318	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 4
051319	AREA SMOKE DETECTOR	
051320	AREA SMOKE DETECTOR	SMOKE IN SUB 41N
051321	AREA SMOKE DETECTOR	
051322	MANUAL PULL STATION	
051323	MANUAL PULL STATION	PULL STATION IN SUB
051324	MANUAL PULL STATION	
051401	AREA SMOKE DETECTOR	ACS-41-10 AREA ALARM
051402	DUCT SMOKE DETECTOR	ACS-41-10 DUCT ALARM
051403	AREA SMOKE DETECTOR	ACS-41-6 AREA ALARM
051404	DUCT SMOKE DETECTOR	ACS-41-6 DUCT ALARM
051405	AREA SMOKE DETECTOR	ACS-41-2 AREA ALARM
051406	DUCT SMOKE DETECTOR	
051407	DUCT SMOKE DETECTOR	ACS-41-2 DUCT ALARM
051408	DUCT SMOKE DETECTOR	
051409	DUCT SMOKE DETECTOR	ACR-41-4 SHUTDOWN
051410	DUCT SMOKE DETECTOR	
051411	DUCT SMOKE DETECTOR	ACR-41-5 SHUTDOWN
051412	DUCT SMOKE DETECTOR	
051413	DUCT SMOKE DETECTOR	ACR-41-6 SHUTDOWN
051414	DUCT SMOKE DETECTOR	
051415	DUCT SMOKE DETECTOR	E-41-19 EXH FAN SHUTDOWN
051416	DUCT SMOKE DETECTOR	E-41-17 EXH FAN SHUTDOWN
051417	DUCT SMOKE DETECTOR	E-41-16 EXH FAN SHUTDOWN
051418	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 4
		SMOKE IN TEL CLOS 4
052101	TAMPER SWITCH	TAMPER SWITCH 41 M
052102	WATER FLOW SWITCH	WATER FLOW 41 MER
052103	PURGE SWITCH 41 NE	PURGE SWITCH ON 41
052104	PURGE SWITCH 41 NW	PURGE SWITCH ON 41
052105	PURGE SWITCH 41 SE	PURGE SWITCH ON 41
052106	PURGE SWITCH 41 SW	PURGE SWITCH ON 41